

Junior Bubble Kit Instructions *(Keep for future reference)*

Before You Begin

- Remove all packaging before giving the wand to a child.
 - Adult supervision is required at all times.
 - Only use outdoors in a safe, enclosed area, away from traffic and trip hazards.
-

Using the Tri-String Bubble Wand

 Watch a demo:
www.bubblyheaven.co.uk/blog/how-to-use-a-tri-string-bubble-wand-triangle-shape-wand

1. Unwind the string. Hold one handle in each hand, no tangles. Let the string hang down.
2. Dip both handles (pressed together) into the solution until the rope is fully submerged.
3. Lift both handles up slowly, still together, until arms are raised up high.
4. Wait a few seconds to let drips fall back—count down “3, 2, 1... blast off!”
5. Open handles slowly to form a bubble. Let the wind do the rest, or move gently to create air movement.
6. To make more bubbles: open and close the wand slowly—**do not shake or swing**.

Top Tip:

Only **dip and lift**—don't stir or swish the solution, or it'll get too foamy. Let foam settle if needed or skim it off.

Cleaning & Storage

- Rinse the wand with water and let it air dry.
 - Wind the string around the sticks to avoid tangles. Tuck the tube piece in between the sticks.
 - Store away from children and pets.
-

Explore More Fun

 Check out bubble music + 25 bubble games:
www.bubblyheaven.co.uk/blog/how-to-play-with-bubbles



-  **Always supervise children.**
Not for children under 3 years old – contains small parts.
Choking & strangulation hazard – contains string.
Slip hazard – clean spills right away.
Wash hands after use.
 -  Domestic use only.
-